COMPANIONS

TRUSTED SINCE 1941



OWNERS MANUAL

Part No. COMP25345



IMPORTANT: Read these instructions for use carefully. Keep these instructions for future reference.

IMPORTANT SAFETY INSTRUCTIONS

Please read instructions before using the unit.

Operate only with water within the temperate range from 10°C to 50°C .

Do NOT allow children to use the appliance unless under supervision of an adult.

Do NOT use the shower while battery is charging.

WARNING

Do not leave appliance unattended when in use. Switch the unit off and remove from water when not in use

Fully charge the battery before first use.

Do not use the shower with any liquid other than water.

Ensure that the base of the pump is fully submerged in water.

Recharge the pump only by DC power output: 5V, 0.5-2A only.


Do not use damaged power cord or plug and charge only with correct voltage as listed. Using improper output voltage may result in damage to the pump motor and may cause possible injury to the user.

Before use, ensure that there are no broken or worn parts.

Keep the appliance away from open fire.


Do not attempt to disassemble the appliance.

UNDERSTANDING YOUR APPLIANCE




ASSEMBLY


Step 1. Attach inlet connector to pump and tighten by turning clockwise. Ensure a tight connection to avoid leakage.



Step 2. Insert O-ring into outlet connector.




Step 3. Attach outlet connector to shower head and tighten by turning clockwise. Ensure a tight connection to avoid leakage.




OPERATION INSTRUCTIONS


Step 1. Push the shower head up to turn it 'OFF'




Step 2. Remove pump safety cap and push on/off switch to start the pump.




Step 3. Put pump into water.



Step 4. Position shower head using the shower head bracket and hook or suction cup.



Step 5. Press the shower head down to turn it "ON"



IMPORTANT


Switch off the pump before removing it from water.

Pump will still run when the shower head is turned off. Don't leave the shower head switch in the off position for more than 5 minutes as it will affect the life of the pump.


Ensure the shower head is securely mounted before use.

RECHARGING

Remove charging socket cover by turning it anticlockwise 1/4 turn.



Insert USB charging cable into charging socket.



Use the following USB charging options:

- DC 12-24V car adaptor [4-5 hours]
- Laptop with USB port [4–5 hours]

The charging indicator (located in the charging socket) will glow:

Red: charging Blue: fully charged

Refit charging socket cover clockwise 1/4 turn to tighten.

^{*[}approximate charging time]

AUTOMATIC STOP

The shower will stop automatically when the battery voltage is lower than 2.7V to protect the battery.

Note: Please do not restart the unit. Fully charge the shower before next use.

GENERAL MAINTENANCE

STORING THE SHOWER

Stop the unit by pressing the on/off switch. Refit safety cap.

Remove hose from pump and shower head. Drain any water from hose.


IMPORTANT:

Ensure that the shower is dry and clean before storing into carry bag.

Store the pump away from high temperature, freezing, flammable and explosive items.

FILTER CLEANING

Step 1. Remove filter cover.



Step 2. Clean the filter and filter cover using clean fresh water only.

Step 3. Replace filter and filter cover securely. Ensure the filter is dry before it is replaced.

BATTERY MAINTENANCE

Fully charge the battery after each use.

Recharge the battery at least every three months to ensure it remains in a fully charged state.

MAINTENANCE AND SERVICE

For more information in Australia call 1300 555 197 or email: service@companionbrands.com.au

SPECIFICATIONS

| Battery Voltage | 3.7V |
|------------------|------------------------------|
| Battery Capacity | 2850 mAh |
| Run Time | 70 minutes approximately |
| Water Flow | 3 L/min (average) |
| Charging Power | USB output of 5V, 0.5 - 2A |
| Power Supply | Built-in Lithium-ion Battery |
| Charging Time | 4–5 hours* |

^{*} See recharging instructions

WARRANTY - For details see www.companionleisure.com.au/warranty

Companion® is a registered trademark of

Primus Australia Pty Ltd

Designed & Imported by: **Adventure Trading Australia Pty Ltd** 71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA

Made in China