

## TV support for flat screens Installation instructions

### **Warning:**


- Read these instructions before use
- Fitting only by a qualified person
- Maximum weight capacity is 7Kgs.

Make sure that fitting will be done in the correct following order.

Please check that the shelf or bottom of the cabinet is strong enough to carry the weight of the bracket and LCD screen.

**1**


### **Fitting of the bracket under a shelf / bottom of cabinet**



- A. Use the mounting bracket as a template to mark the 4 holes on underside of the shelf or bottom of the cabinet.
- B. Once marked drill 4 holes through the shelf or bottom of the cabinet.
- C. Place the mounting bracket over the holes and fasten to the shelf or bottom of the cabinet with the supplied bolts (see picture above).

**2**

### **Fitting of the bracket to the flat screen**



Fit the bracket to the back of the LCD screen with the bolts supplied.